

AB60120WB - Instructions



1. Screw in the spring feet to the metal frame.



2. Insert the assembled frame into the slots in the base.



3. Bolt the frame to the base using the bolt and washer supplied.



4. The unit is ready to use. As an option, fill the base with water or sand for a weighted base.