Attaching Showcase Lock



1. Slide both doors to the left. Slide the notched bar over the inside door.



2. Tighten the screw on the back of the notched bar.



3. Slide the top door over the notched bar. Slide both doors until the end.



4. Slide the lock over the notched bar. Make sure the flat edge rest against the edge of the top door.



5. Use the supplied key to lock the noticeboard.



6. Noticeboard is now secured.