

**User Manual** 

Model:CLCTWL10

### Contents

A. Description and Function 1	l
B. Intended Use 1	I
C. Notes on Safety 1	I
D. Package Content	3
E. Connecting and Operating	3
F. Care, Maintenance, Storage and Transport	5
G. Specifications	3
H. Warranty and Liability6	6

- I. Troubleshooting...... 7
- J . Note on Waste Disposal..... 8


### A Description and Function:

The product is a desktop charger. It is ideal for hotel rooms, restaurants, bars & cafes.

# B Intended Use:

It is not allowed to use the device in other ways than described in chapter "Description and Function" Use this device only in dry interior rooms. The symbol with the house reminds you of that. If you do not attend to these regulations and notes on safety, it might causes fatal accidents, injuries and damages to persons and property.

### C Notes on Safety:



This product is not a toy and is not meant for children, because it contains small parts which can be swallowed and can injure when used inappropriately!

Please install the system and devices attached to it in a way that
persons cannot be injured, or objects not be damaged for example
by dropping and stumbling.

 Please remove the packing materials, because children may cut themselves on them while playing. Furthermore, there is a risk of swallowing and inhalation of incidentals and insulating material.
 Avoid places with high temperatures, or humidity, or places which

Avoid places with high temperatures, or humidity, or places which
might come into contact with water.

 Do not install the product close to openings of air conditioners, or at places with an excessive amount of dust, smoke or vibrations.
 Place the product only on horizontal and flat surfaces to avoid fallian

Do not modify and alter the product and any accessories! Make sure you also read the Chapter "Warranty and Liability".
Do not use any damaged parts.

· Plug and unplug all cables / adaptors slowly and carefully.

During transport, observe the details listed in the Chapter
 "Specifications", and implement measures suitable for transport,
e.g. use the original package.

 For questions, defects, mechanical damages, malfunctions, and other functional problems which cannot be resolved by this manual, please contact your dealer for repair or replacement, as described in the Chapter "Warranty and Liability".

Mind Chapter "Specifications".
Please also observe the terms of use decribed in the Chapter

"Intended Use"

### (D) Package Content:


1 pc AC Adaptor (100 ~ 240V / 50~60 Hz) 1 pc Power Cord (Optional: UK/US/EU/AUZ) 1 pc Desktop Charger 1 pc Acrylics Table Tent

1 pc User Manual

### (E) Connecting and Operating:

- Connect the included power cord to the wall socket and AC adaptor then to HOQi Desktop Charger to charge it.
- Security lock hole to be used with Kensington laptop lock (not included).

3A.Insert A5 advertisement in acrylic table tent (optional).3B.Install table tent in the hole at the back of the HOQi and secure it with screws.



## **F** Care, Maintenance, Storage and Transport

ATTENTION! There is a risk of electric shocks and short circuit!

- The device is maintenance-free.
  Always disconnect the mains plug from mains at first!
- Use a dry linen cloth to clean your product, or use a slightly moist cloth for heavy stains. Look out for live cables of your device during cleaning! Do not use any cleaning supplies and avoid liquid entry to the device.

 Avoid the risk of stumbling during installing the mains Power Cord and adaptor plugs.

Avoid places with high temperatures, humidity, or places which can become wet, also during care, maintenance, storage and transport.
Mind the notes on safety also regarding care, maintenance, storage

and transport.

Use the original packaging as protection from dust and humidity for transporting.



12V/3A
5V/1.0A x 2
5V/1.5A x 1
5V/1.0A x 1 (Charging distance: not more than 6mm)
520g
122 x 122 x 44 mm
CE, ROHS
CLCTWL10

### H Warranty and Liability:

The manufacturer grants a 12 months warranty to a new device.
As the manufacturer has no influence on installation, warranty of the

product only applies to the product.

If any fault or damage is detected on your device, please contact your dealer and provide your sales slip or invoice as evidence of the

purchase, if necessary. Your dealer will repair the fault either on site or send the device to the manufacturer. You make the work of our technicians considerably easier, describing the possible faults in detail. If your dealer cannot be contacted, you can also contact us directly. • The manufacturer is not liable for damages to persons or property caused by improper installation oroperation not described in this guide. This includes, among others, any alternation and modification of the product and its accessories.

 Any use other than described in this user manual is not permitted, and causes loss of warranty, loss of guarantee, and non-liability.
 We reserve our right for misprints and changes of the device, packing or user manual.

### (I) Troubleshooting:

	Problem	Help
	The device does not charge	<ul> <li>When the device is charged completely, no charging is shown.</li> <li>Check all connections for tight fitting.</li> </ul>
	Failure of the Female USB function	Make Sure using a fitting and compatible USB charging cable.
	Other problems	Consult your dealer.

### (J) Note on Waste Disposal:

In according to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. The consumer is committed by law to reposit electrical and electronic devices to public collecting points or to the dealer at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the manual or at the packaging alludes to these terms. With this kind of application of used devices you achieve an important share to environmental protection.

#### ATTENTION !

Please read the user manual completely and carefully. It is part of the product and includes important information for proper installation and use. Keep this guide to have it available, hen there are uncertainties, or the product will be passed on.

3A 3A 3B 3B 4



8