

L Banner Instructions





1. Open the hinged graphics strip



2. Insert the banner and close the strip to secure. Repeat this process on the other end of the banner



3. Insert the base into the slot on the lower graphics strip



4. Extend the support pole to the correct length. Twist to lock each section as illustrated



5. Insert the bottom of the support pole firmly into the hole in the base



6. Insert the top of the support pole into the slot on the upper graphics strip. Adjust the support pole to achieve satisfactory tension

[©] Copyright 2013 and Intellectual Property reserved. Not to be used for any purpose without the express written authorisation of Jessen Group Pty. Ltd. All information is intended as a guide only and is subject to change without notice.