




Item: WCH24FSBK Greeting Card Display Racks




Wire Frame x 1



Metal Base x 1



Poles x 2
(Top and Bottom with hole)



4. Sign Holder x 1
5. Bearing x 1
6. Flat Plate x 1
7. Pin x 1

ASSEMBLY INSTRUCTIONS

1. Ensure all components are present prior to installation.
2. Put Bottom Pole (3) into the Metal base (2).
3. Put the Pin (7) into the hole of Bottom Pole (3), and put Flat Plate (6) and Bearing (5) on the pin.
4. Put Top Pole on the Bottom Pole
5. Slide Wire Frame (1) over the pole from the top until it rest on the bearing (5).
6. Put Sign Holder (4) on the top of pole.

