

Cleaning Instructions for ASHMA5



1. Unlock the ashtray using the key provided



2. Lift the cannister out of the pole



3. Place a garbage bag close to the bottom of the ashtray.

4. Open the bottom cover of the ashtray using the key provided.

5. Swing the bottom cover open and empty the content into the garbage bag



6. Use the brush provided to clean the bottom cover.

7. Using mild soap, clean the body of the ashtray with a damp cloth.